

R12/17C...R40/17C

Version: PROF+A2

en Assembly and Operating Instructions

Roller shutter drive with integrated radio receiver 915.3 Mhz

Important information for:

• Fitters / • Electricians / • Users

Please forward accordingly!

These instructions must be kept safe for future reference.



Table of contents

General	3
Warranty	5
Safety instructions	5
Intended use	7
Assembling and disassembling the plug-in connecting cable	7
Assembling the plug-in connecting cable	7
Disassembling the plug-in connecting cable for tubular drives dia. 45 and dia. 58	8
Installation	9
Assembling the drive	9
Undoing the mounting pin	9
Drive adapter for obstacle detection	9
Assembling the drive adapter with drive adapter safety catch	10
Assembling the drive adapter with screw connection	10
Securing the drive against axial displacement	10
Fixing the drive adapter to the barrel dia. 45	10
Mounting the drive in the tube	11
Confirming the drive	11
First operation	12
Programming the master transmitter	13
Checking that the running direction is correct	13
Intelligent installation management	13
Setting the limit positions	14
Upper stop to lower stop	14
Upper point to lower point	14
Upper stop to lower point	14
Upper point to lower stop	15
Changing the set limit positions	15
Deleting the limit positions	15
Intermediate positions I + II	16
Programming additional transmitters	17
Deleting transmitters	17
Overwriting the master	18
Upper anti-freeze mechanism	19
Activating/Deactivating upper anti-freeze mechanism	19
Obstacle detection	19
Fly screen protection function	20
Programming the run times	20
Deleting the run times	21
Disposal	21
Maintenance	21
Technical data dia. 45	21
What to do if...?	22
Sample wiring diagram	23
Declaration of conformity	24

General

These tubular drives are high-quality products with the following features:

- Optimised for roller shutter operation
- Individual, group and central radio control
- No need to run wires to a switch or relay control device
- Any combination of drive and transmitter possible
- Simple to set the limit positions with the transmitter
- Installation without stops possible (from upper point to lower point)
- Two freely selectable intermediate positions can be set
- Flexible radio grouping; can be altered at any time with no need to install/uninstall
- Integrated memo function facilitates easy programming of one or two switching times on daily repeat.
- Automatic detection of the lower limit position when using springs in conjunction with the "drive adapter for obstacle detection"
- Automatic detection of limit positions thanks to intelligent electronic system with stop systems
- Obstacle detection, even when using anti-lifting devices (axle shaft devices)
 - Secure anti-lifting device
 - Slight pressure applied to the roller shutter curtain makes it difficult to raise or reach under it
 - Suitable for rigid aluminium, steel and wooden profiles
- The final positions do not have to be reset: Changes in the shading solution are accommodated automatically when using stop systems.
- Torque control in the up direction prevents damage to the roller shutter in the event of a frozen or blocked shutter
- Anti-freeze mechanism in the upper limit position can be enabled
- Considerably lower stop load, and thus considerably lower shading solution load.
- Smooth operation of the system and the drive increases the service life
- For plug-in connecting cable
- Fly screen protection function

Please observe these Assembly and Operating Instructions when installing and setting the equipment.



Note

In order to identify the type of drive, compare the type plate of the tubular drive with the cover of these instructions.



Explanation of nomenclature

Tubular drives:

Example: R12/17C PROF+

R	12	/	17	C	PROF+
Type	Nm		min ⁻¹	C-Plug = plug-in connecting cable	Limit switch version

Types:

P = pico tube dia. 35 mm

R = regular tube dia. 45 mm

L = large tube dia. 58 mm

Limit switching versions:

M = mechanical limit switch

HK = mechanical limit switch with crank

G = DC drives with mechanical limit switch

GHK = DC drives with mechanical limit switch and crank

Electronic limit switching:

R = roller shutters

S = sun protection

F = with integrated radio receiver

P = with point-to-point switching

E = reversing in the limit position

O = with sensitive obstacle detection

SMI = Standard Motor Interface

+ **(with R)** = with automatic detection of anti-lifting devices

+ **(with S)** = higher closing force for cassette awnings

Software versions

A0...z9

The date of manufacture comes from the first four digits of the serial number.

The numbers 1 and 2 indicate the year and the numbers 3 and 4 indicate the calendar week.

Example: 24th calendar week in 2012

Ser. No.:	1224XXXXX
-----------	-----------

Explanation of pictograms

	Caution Denotes a potentially hazardous situation. If this is not avoided, injuries may result.
	Attention Denotes a potentially hazardous situation. If this is not avoided, the product or something in its vicinity may be damaged.
	Note Denotes user tips and other useful information.

Warranty

Structural modifications and incorrect installation which are not in accordance with these and our other instructions can result in serious injuries, e.g., crushing of limbs. Therefore, structural modifications may only be carried out with our prior approval and strictly in accordance with our instructions, particularly the information contained in these Assembly and Operating Instructions. Any further processing of the products which does not comply with their intended use is not permitted.

The end product manufacturer and fitter have to ensure that all the relevant current statutory, official and, in particular, EMC regulations are adhered to during utilisation of our products, especially with regard to end product manufacture, installation and customer advice.

Safety instructions

The following safety instructions and warnings are intended to avert hazards and to prevent property damage and personal injury.

Please keep these instructions in a safe place.



Caution

Important safety instructions for the user.

Failure to observe these instructions can lead to serious injuries.

- **All work, including maintenance and cleaning, on electrical installations as well as other system parts must always be performed by authorised specialists, in particular qualified electricians.**
- **Do not allow children to play with control units.**
- **Systems have to be checked regularly by authorised specialists for wear and damage.**
- **Always put damaged systems out of operation immediately until they are repaired by an authorised specialist.**
- **Do not operate equipment if people or objects are within the danger zone.**
- **Observe the danger zone of the equipment during operation.**
- **Stop and disconnect the equipment from the mains power supply when maintenance and cleaning is being performed either on the system itself or in the immediate vicinity of it.**
- **Ensure that there is adequate clearance (at least 40 cm) between moving parts and adjacent objects.**
- **Crushing or shearing points must be avoided or protected.**





Caution

Important safety instructions for installation and commissioning

Failure to observe these instructions can lead to serious injuries.

- **Observe the safety instructions in EN 60335-2-97. Please note that this list of safety instructions is not exhaustive, since it would be impossible for the standard to include all sources of danger. For example, the design of the operated product, the way the drive works in the situation it is installed in or even the way the end product is mounted in the end user's place of use cannot be taken into consideration by the drive manufacturer.**

If any questions or uncertainties regarding the safety instructions contained in the standard arise, please contact the manufacturer of the part or end product in question.

- **All work, including maintenance and cleaning, on electrical installations as well as other system parts must always be performed by authorised specialists, in particular qualified electricians.**
- **When electrical or electronic equipment and units are operated, certain components, e.g., the power supply unit, are live. Physical injuries or damage to property can result in the event of unauthorised interventions or failure to heed warnings.**
- **Be careful when touching the tubular drive, as it heats up during operation for technological reasons.**
- **All applicable standards and regulations for electrical installation must be complied with.**
- **Only use spare parts, tools and accessory devices which have been approved by the drive manufacturer.**
- **Unapproved third-party products or modifications to the system and its accessories represent a risk to your safety and the safety of others. This means that the use of unapproved third-party products, or modifications which have not been agreed with or approved by us, are prohibited. We do not accept liability for damages or injury arising from such actions.**
- **Before installation, shut down all lines and control devices that are not essential for operation.**
- **Position control devices within sight of the driven product, but away from moving parts, at a height of over 1.5 m.**
- **Permanently mounted control devices must be positioned where they can be seen.**
- **Ensure that there is adequate clearance between moving parts and adjacent objects.**
- **Rated torque and duty cycle must be suitable for the requirements of the driven product.**
- **Technical data – rated torque and service life can be found on the type plate of the tubular drive.**
- **Moving parts of drives must be installed at a height of over 2.5 m above floor level or any other surface from which access to the drive is gained.**
- **Crushing or shearing points must be avoided or protected.**
- **When installing the drive, all-pole disconnection from the mains with a contact gap of at least 3 mm per pole must be provided (EN 60335).**
- **To ensure safe operation of the system after commissioning, the limit positions must be correctly set/programmed in.**
- **If the drive mains connecting cable is damaged, it must be replaced with the same type of mains connecting cable, which is available from the drive manufacturer.**
- **The drive must not be carried by the mains connecting cable.**
- **Drives with a H05VV-F connecting cable may only be used indoors.**
- **To connect the drive to the driven part, solely mechanical accessory components made by the drive manufacturer from the current product catalogue may be used. The components must be installed in accordance with the manufacturer's instructions.**
- **All latching connections and fastening screws on the brackets must be checked to ensure that they are secure.**
- **If the drive is used for curtains in a specially marked area (e.g. escape routes, hazard zones, safety areas), compliance with all applicable regulations and standards must be ensured.**

Intended use

The type of tubular drive described in these instructions is intended solely for the operation of roller shutters.

This type of tubular drive supports not only curtain attachment by means of springs but also mechanical anti-lifting devices (e.g., Zurfluh-Feller, Simu, GAH Alberts and Deprat). These are detected automatically.

If the springs or the top lath are not screwed or rivetted to the barrel, a point must be set in the lower limit position.

This type of tubular drive is designed for use in single systems (one roller shutter curtain per barrel and drive).

For sunblinds, please use only the types of tubular drive designed for this purpose.

The tubular drive must not be used in potentially explosive areas.

The mains connecting cable is not suitable for transporting the drive. Always carry the drive by the housing tube.

Other applications, uses and modifications are not permitted in order to protect the safety of the users and others, since these actions can impair the system's safety and carry the risk of personal injury and property damage. The drive manufacturer does not accept liability for damages or injury arising from such actions.

Always observe the information in these instructions when operating or repairing the system. The drive manufacturer does not accept liability for damages or injury resulting from improper usage.



Attention

Only use anti-lifting devices if the roller shutter laths are sufficiently strong. The closed curtain must not project beyond the guide tracks or else there is a risk of the joint between the top two laths being subjected to excessive strain and getting damaged.


Assembling and disassembling the plug-in connecting cable

Assembling the plug-in connecting cable

Insert the **dead** connecting cable into the drive head until the locating lug clicks into place in the drive. If necessary, use a suitable flathead screwdriver to assist with insertion. Set the screwdriver into one of the two plug grooves provided for this purpose.

Check that the cable is properly engaged.

C+plug



1 = locating lug



Disassembling the plug-in connecting cable for tubular drives dia. 45 and dia. 58



Caution


Prior to disassembly, the power supply to the connecting cable must be disconnected.

On drives with a diameter Ø45 or Ø58, insert a suitable flathead screwdriver right into the recess of the locating latch, so that the latch releases the locating lug from the plug.

Now you can pull out the connecting cable along with the flathead screwdriver.

dia. 45 and dia. 58

C+plug



A = locating latch

Installation

Assembling the drive



Attention

To connect the drive to the driven part, solely mechanical accessory components made by the drive manufacturer from the current product catalogue may be used.

Prior to mounting, the fitter must ensure that the masonry and the system being motorised are sufficiently robust (drive torque plus weight of the shading solution).




Caution

Electrical connections may only be carried out by a qualified electrician. Prior to assembly, the power supply must be disconnected and secured. Please give the enclosed connection information to the responsible electrical contractor.

These drives cannot be operated with conventional switching elements (switches, timers and the like).

If you want the roller shutter curtain to open to the upper stop, proceed as follows: The roller shutter curtain must be prevented from being drawn into the shutter box with a mechanical stop or an angled end strip. With face-fixed elements, we recommend concealed stops in the guide tracks.



Calculate the space required at the side (M) by measuring the drive head and wall bracket. The clear dimension of the box (X) minus the space required at the side (M) and idler (G) gives the length (L) of the barrel: $L = X - M - G$.
The space required at the side (M) varies depending on the combination of drive and wall bracket.


Then mount the wall bracket and idler. Ensure that the barrel is aligned at right angles to the wall and that sufficient axial play is allowed for the mounted system.



Attention

When using anti-lifting devices, closed brackets must be fitted. The tubular drive presses the closed curtain down to make it difficult for people to reach under it or raise it. Only use curtains made of sufficiently strong material, such as aluminium, steel or wood. To prevent damage to the curtain it must run in guide tracks from top to bottom.

Undoing the mounting pin



When pushed in, the mounting pin (2) locks automatically. To undo the mounting pin (2), push the tab washer (1) upwards and pull out the mounting pin (2).

Drive adapter for obstacle detection




Note

If you wish to use the "obstacle detection" function, you must use the "drive adapter for obstacle detection".




Assembling the drive adapter with drive adapter safety catch




Put the drive adapter (1) onto the drive shaft of the tubular drive. You can see which way to insert the safety catch (2) from its shape. When inserting the drive adapter safety catch (2) into the hole (4), make sure that the locking lug (3) engages. You will hear a click. Check that the safety catch is securely in position by pulling on the drive adapter (1).

Assembling the drive adapter with screw connection



Put the drive adapter (1) onto the drive shaft of the tubular drive. For the assembly, use an M6 x 12 screw (3) with appropriate washer (2) and suitable screw retainer. Threaded hole (4)

Securing the drive against axial displacement



In order to secure the drive against axial displacement, we recommend screwing the drive adapter to the tube.



Attention
When drilling into the barrel, never drill near the tubular drive!

Fixing the drive adapter to the barrel dia. 45


Size of drive [mm]	Diameter of barrel [mm]	Torque max. [Nm]	Fastening screws for drive adapter (4 pc.)
dia. 45	60 - 70 mm plastic or diecast drive adapter	40	Self-tapping screw dia. 4.8 x 9.5 mm

We also recommend screwing the opposite end bracket to the barrel.




Attention
Do not hammer or drop the tubular drive into the barrel! The curtain can only be secured using springs or anti-lifting devices.

Mounting the drive in the tube




For profile tubes:

In the case of some drive adapters, tolerances of the groove widths in different barrels can be offset by rotating the drive adapter into a different groove recess. These groove recesses have different sizes and allow the drive to fit exactly.



For round tubes:

First notch the tube on the motor side, so the lug of the thrust ring can also be pushed into the tube. There must be no play between the lug of the thrust ring and the tube. For rings without drive lugs, which are used to assist fitting on the thrust ring, the barrel must be connected to the thrust ring by a 4.8 x 9.5 mm self-tapping screw.



Assemble the tubular drive with the relevant thrust ring (1) and drive adapter (2). Insert the tubular drive with the pre-assembled thrust ring and drive adapter into the tube to achieve a form fit. Ensure that the thrust ring and drive adapter are secure in the tube.


Mount the assembled unit comprising barrel, tubular drive and idler on the box and secure the drive according to the type of wall bracket fixing with a split or spring pin.

After programming the transmitter, position the barrel so that the roller shutter curtain can be mounted with springs or fit the anti-lifting device in accordance with the manufacturer's instructions.



Note

When using springs/anti-lifting devices, we recommend you use at least three; for longer tubes, use three springs/anti-lifting devices per meter of barrel.



Lay the connecting cable

Lay the connecting cable up to the tubular drive, and fix. The connecting cable and any antennae must not project into the winding chamber. Cover any sharp edges.




Confirming the drive


The drive audibly confirms each programming and deletion action. The tubular drive makes a barely perceptible movement, which you hear as a "click" or "click click" sound.




First operation

Explanation of symbols


	UP button
	STOP button
	DOWN button
	Programming button
	The tubular drive clicks once to confirm
	The tubular drive clicks twice to confirm
	The tubular drive clicks three times to confirm
	1 = direction switch 2 = radio switch

230V AC / 50 Hz  1 = blue 2 = brown 3 = black 4 = green-yellow	Connecting the tubular drive Connect the tubular drive to the power supply.
	Readying the tubular drive for programming Readying the tubular drive for programming by switching on the power ⇒ Switch on the power. ➡ The tubular drive is ready to programme for 3 minutes

 **Note**
If several tubular drives are to be connected in parallel, you can deactivate the programming mode on one tubular drive by switching the radio switch to the outside position after turning the power on.

	Readying the tubular drive for programming with the radio switch Switch the radio switch to the inside position. If the radio switch is already in this position, switch it to the outside and back to the inside position. ➡ The tubular drive is ready to programme for 3 minutes
--	---

Programming the master transmitter

	Press the programming button for 3 seconds when it is ready to programme. ⇒ The tubular drive makes a clicking sound to confirm. ➔ The programming process is now complete.
---	--



Note

If a transmitter is already programmed on the receiver, press the programming button for 10 seconds.

Checking that the running direction is correct





Note

It is only possible to change the direction of rotation if no limit position has been set.

Press the UP or DOWN button

- ⇒ The shading solution runs in the desired direction.
- ➔ Direction switch is OK.

If the shading solution runs in the wrong direction, the running direction must be switched. Proceed as follows:



Switch the direction switch (1) to the opposite position.

- ➔ The shutter direction is now changed.
- Check the shutter direction again.

Intelligent installation management

Limit position status indicator

A brief stopping and restarting indicates that no limit position has been set in that direction of movement.

Completion of installation following automatic setting of limit positions

The drive saves the limit position permanently once the upper limit position is reached 3 times in succession. Installation is then complete. If the limit position is set above a point, this is stored permanently.



Setting the limit positions

**Note**

The limit positions can only be set with the master transmitter. The shutter direction must be correct. When setting the limit positions, the tubular drive runs in dead-man mode and limit position status indicator. The upper limit position must always be set first. When setting the upper limit position, ensure that the roller shutter curtain is not pulled out of the guide tracks.

When first installing, using springs and adjusting the limit position ‘...to lower stop’, the barrel in the lower limit position turns approx. 1/4 of a turn further than usual. In doing so, the tubular drive is able to automatically detect the use of anti-lifting devices or springs. The tubular drive switches off automatically.

**Attention**

When operating the tubular drive without the drive adapter for obstacle detection, if using springs a point must be set in the lower limit position.

There are 4 ways to set the limit positions:

- Upper stop to lower stop
- Upper point to lower point
- Upper stop to lower point
- Upper point to lower stop

The limit position becomes fixed after the tubular drive has turned off **automatically** in the desired position three times.



Upper stop to lower stop

	Open to the permanent upper stop. ⇒ The tubular drive switches off automatically.
	Then close to the permanent lower stop. ⇒ The tubular drive switches off automatically. ➡ The limit positions are now set.


Upper point to lower point

**Note**


There is no shading solution length adjustment with this limit position setting.

	Open to the desired upper limit position.
	Press the programming button and, within 3 seconds, also press the UP button and hold the two buttons down. ⇒ The tubular drive makes a “click” sound to confirm.
	Then close to the desired lower limit position.
	Press the programming button and, within 3 seconds, also press the DOWN button and hold the two buttons down. ⇒ The tubular drive makes a “click” sound to confirm. ➡ The limit positions are now set.

Upper stop to lower point

	Open to the permanent upper stop. ⇒ The tubular drive switches off automatically.
	Then close to the desired lower limit position.
	Press the programming button and, within 3 seconds, also press the DOWN button and hold the two buttons down. ⇒ The tubular drive makes a “click” sound to confirm. ➡ The limit positions are now set.

Upper point to lower stop

	Open to the desired upper limit position.
	Press the programming button and, within 3 seconds, also press the UP button and hold the two buttons down. ⇒ The tubular drive makes a “click” sound to confirm.
	Then close to the permanent lower stop. ⇒ The tubular drive switches off automatically. ➔ The limit positions are now set.

Changing the set limit positions



Note

Once set, the limit positions can only be changed with the master transmitter.

1) Shortening the range of travel (the desired limit position is located inside the current range of travel)


	Open/close to the desired new limit position.
	Press the programming button and, within 3 seconds, also press the DOWN button for the lower limit position or the UP button for the upper limit position and hold the two buttons down. ⇒ The tubular drive makes a “click” sound to confirm. ➔ The new limit position is now saved.

2) Extending the range of travel (the desired limit position is located outside the current range of travel)



Attention

When both or individual limit positions are deleted, all the other set functions (intermediate position I, intermediate position II, upper anti-freeze mechanism, obstacle detection, run times, fly screen protection function) are deleted as well.

	Open/close to the limit position in the direction in which you wish to extend the range of travel.
	Press the programming button and, within 3 seconds, also press the STOP button and hold the two buttons down for 10 seconds. ⇒ The tubular drive makes a clicking sound to confirm. ➔ The limit position is now deleted.
	Open/close to the desired new limit position.
	Press the programming button and, within 3 seconds, also press the DOWN button for the lower limit position or the UP button for the upper limit position and hold the two buttons down. ⇒ The tubular drive makes a “click” sound to confirm. ➔ The new limit position is now saved.

Deleting the limit positions



Attention

When both or individual limit positions are deleted, all the other set functions (intermediate position I, intermediate position II, upper anti-freeze mechanism, obstacle detection, run times, fly screen protection function) are deleted as well.



**Note**

Once set, the limit positions can only be deleted with the master transmitter. Deleted limit positions are displayed on the limit position status indicator.

Deleting individual limit positions

	Open/close to the limit position to be deleted.
	Press the programming button and, within 3 seconds, also press the STOP button and hold the two buttons down for 10 seconds. ⇒ The tubular drive makes a clicking sound to confirm. ➔ The limit position is now deleted.

Deleting both limit positions

	Open/close the shading solution to a point between the limit positions.
	Press the programming button and, within 3 seconds, also press the STOP button and hold the two buttons down for 10 seconds. ⇒ The tubular drive makes a clicking sound to confirm. ➔ The limit positions are now deleted.

Intermediate positions I + II**Note**

The intermediate positions I + II are freely selectable positions for the shading solution between the two limit positions. Each travel button can be assigned one intermediate position. Both limit positions must be set before the intermediate position is set.

When both or individual limit positions are deleted, both intermediate positions are deleted as well.

Setting the desired intermediate position

	Open/close the shading solution to the desired intermediate position.
	Press the STOP button and, within 3 seconds, also press the desired travel button and hold the two buttons down. ⇒ The tubular drive makes a “click” sound to confirm. ➔ The intermediate position is now saved.

Setting the desired intermediate position

	Press the travel button for the desired intermediate position twice within one second. ➔ The shading solution runs to the intermediate position assigned to the travel button.
--	---

Deleting the desired intermediate position

	Open/close the shading solution to the desired intermediate position.
	Press the STOP button and, within 3 seconds, also press the travel button assigned to the intermediate position and hold the two buttons down. ⇒ The tubular drive makes a clicking sound to confirm. ➔ The intermediate position is now deleted.

Programming additional transmitters



Note

In addition to the master transmitter, up to 15 further transmitters can be programmed in the tubular drive.

	Press the programming button of the master transmitter for 3 seconds. ⇒ The tubular drive makes a “click” sound to confirm.
	Now press the programming button of a new transmitter which has not yet been programmed in the tubular drive for 3 seconds. Doing so activates the programming mode of the tubular drive for a new transmitter for 3 minutes. ⇒ The tubular drive makes a “click” sound to confirm.
	Now re-press the programming button of the new transmitter you wish to programme for 3 seconds. ⇒ The tubular drive makes a clicking sound to confirm. ➡ The new transmitter is now programmed in.

Deleting transmitters

Deleting individual transmitters



Note

The programmed master transmitter cannot be deleted. It can only be overwritten (see Programming the master transmitter [→ 13]).

	Press the programming button on the master transmitter for 3 seconds. ⇒ The tubular drive makes a “click” sound to confirm.
	Now press the programming button of the transmitter to be deleted for 3 seconds. ⇒ The tubular drive makes a “click” sound to confirm.
	Then re-press the programming button of the transmitter to be deleted for 10 seconds. ⇒ The tubular drive makes a clicking sound to confirm. ➡ The transmitter is now deleted from the tubular drive.

Deleting all transmitters (except the master transmitter)

	Press the programming button on the master transmitter for 3 seconds. ⇒ The tubular drive makes a “click” sound to confirm.
	Re-press the programming button on the master transmitter for 3 seconds. ⇒ The tubular drive makes a “click” sound to confirm.
	Re-press the programming button on the master transmitter for 10 seconds. ⇒ The tubular drive makes a clicking sound to confirm. ➡ All transmitters (except the master transmitter) are now deleted from the receiver.



Overwriting the master



There are two ways to overwrite the master:

- Readying the tubular drive for programming by switching on the power
- Readying the tubular drive for programming with the radio switch




Readying the tubular drive for programming by switching on the power

**Note**

To ensure that the new master transmitter is programmed in the desired tubular drive only, all other tubular drives which are connected to the same power supply must be deactivated from the programming mode. To do so, after switching back on the power, execute a drive or stop command using the transmitter for the given tubular drives or switch the radio switch from inside to outside. If the radio switch is already in this position, switch it to the inside and back to the outside position.

230V AC / 50 Hz  1 = blue 2 = brown 3 = black 4 = green-yellow	Switch off the tubular drive power for 5 seconds, then switch it back on. ⇒ The tubular drive is ready to programme for 3 minutes.
	Now press the programming button of the new master transmitter for 10 seconds. ⇒ The tubular drive makes a clicking sound to confirm. ➔ The new master transmitter is now programmed and the old master transmitter overwritten.

Readying the tubular drive for programming with the radio switch

	Switch the radio switch to the inside position. If the radio switch is already in this position, switch it to the outside and back to the inside position. ⇒ The tubular drive is ready to programme for 3 minutes.
	Now press the programming button of the new master transmitter for 10 seconds. ⇒ The tubular drive makes a clicking sound to confirm. ➔ The new master transmitter is now programmed and the old master transmitter overwritten.

Upper anti-freeze mechanism

The upper anti-freeze mechanism helps to prevent the roller shutter from freezing in the upper limit position, as the roller shutter stops just before the upper stop. The distance from the upper stop is automatically cyclically checked and, if necessary, corrected.

The upper anti-freeze mechanism is deactivated on delivery.

Both limit positions must be set before the anti-freeze mechanism can be activated.



Note

The anti-freeze mechanism only works if a permanent stop is set at the upper limit position of the roller shutter. The anti-freeze mechanism is not visible until the shading solution has reached the upper stop from the lower limit position 3 times in succession.

When both or individual limit positions are deleted, this set function is deleted as well.

Activating/Deactivating upper anti-freeze mechanism

	Open the shading solution to the upper limit position.
	Press the programming button on the master transmitter for approx. 3 seconds. ⇒ The tubular drive makes a “click” sound to confirm.
	Then re-press the programming button and also the STOP and UP buttons for approx. 3 seconds. ➔ The tubular drive clicks 3 times to confirm.

Obstacle detection



Caution

Obstacle detection is only active in conjunction with the “drive adapter for obstacle detection”.

In addition, please note that the drive must be pushed in to the shaft as far as the band of the thrust ring.

If the drive is correctly installed, it switches off when it detects obstructions or shutter faults.

The following are detected:

In the DOWN direction

- A curtain jam when closing due to objects on the window sill or sticking of the lateral guide tracks.

In the UP direction

- Extremely large increase in the load (e.g., ice on the end strip)

To ensure that the roller shutter curtain safely enters the guide tracks, obstacle detection is inactive for approx. 1.5 revolutions of the barrel from the upper limit position.



Fly screen protection function

If the fly screen protection function is activated, obstacle detection is activated after a revolution of the barrel of approx. 140° from the upper limit position. If the roller shutter curtain meets an opened fly screen door, the drive stops and returns to the upper limit position.

The fly screen protection function is deactivated on delivery.

Both limit positions must be set before the fly screen protection function can be activated.



Note

When both or individual limit positions are deleted, this set function is deleted as well.

Activating/Deactivating the fly screen protection function

	Open the shading solution to the upper limit position.
	Press the programming button on the master transmitter for approx. 3 seconds. ⇒ The tubular drive makes a “click” sound to confirm.
	Then re-press the programming button and also the STOP and UP buttons for approx. 3 seconds. ➔ The tubular drive clicks 3 times to confirm.

Programming the run times



Note

This function is only available with MemoControl transmitters from the Becker Centronic range of control units.

When both or individual limit positions are deleted, this set function is deleted as well.

Each tubular drive can each save one switching time for one UP and one DOWN cycle.

In the “Timer” slide switch position, this roller shutter action is repeated every 24 hours.

It does not matter what position the manual/auto slide switch is in when programming the switching time. Any stored switching times are overwritten.

1. If necessary, run the roller shutter to the opposite limit position.
2. Wait for the time you wish the automatic drive command to be executed.
3. At the desired time, press and hold the relevant direction button until the roller shutter drive briefly stops after approx. 6 seconds and then continues to the limit position.
4. Release the direction button.

The tubular drive has saved the current time for this direction of travel.

Deleting the run times



Note

When deleting, both run times are always deleted.

To delete the UP and DOWN run time, press the STOP button for 10 seconds. The tubular drive makes a "click click" sound to confirm.

The run times are now deleted.

Disposal

This product is made of various materials which must be disposed of properly. Find out about the applicable regulations on recycling or disposal for this product in your country.

The packaging material must be disposed of properly.

Maintenance

These drives are maintenance-free.

Technical data dia. 45


Type	R12/17C PROF+A2	R20/17C PROF+A2	R30/17C PROF+A2	R40/17C PROF+A2
Rated torque (Nm)	12	20	30	40
Output speed (rpm)	17	17	17	17
Limit switch range	64 revolutions			
Supply voltage	230 V AC / 50 Hz			
Connected load (W)	110	160	205	260
Rated current consumption (A)	0.5	0.75	0.9	1.15
Mode	S2 4 min			
Protection type	IP 44			
Min. tube inside diameter (mm)	47			
Frequency	915.3 MHz			



What to do if...?

Problem	Cause	Remedy
Tubular drive is not functioning.	No transmitter programmed.	Programme new transmitter.
	Transmitter is out of range of the tubular drive.	Bring transmitter within range of the tubular drive.
	Transmitter was operated out of range several times.	Press drive or stop button on transmitter at least 5 times in the immediate vicinity of the tubular drive.
	Batteries in transmitter not inserted/ inserted incorrectly or dead.	Insert batteries correctly or insert new batteries.
	Electrical connection is faulty.	Check electrical connection.
	Thermal protection switch in tubular drive has tripped.	Wait until the thermal protection switch in the tubular drive is reactivated.
Shutter direction on tubular drive cannot be set.	Limit positions are stored in the tubular drive.	Delete limit positions (see Deleting the limit positions [→ 15]) and reset the direction switch.
Incorrect shutter direction after deleting limit positions.	Direction switch is in the wrong position.	Switch the direction switch to the opposite position.
Tubular drive stops arbitrarily; cannot be restarted in the same direction.	Tubular drive has detected an increase in load.	Briefly run the curtain in the opposite direction, then continue in the desired direction.
	Tubular drive is overloaded.	Use a higher-torque tubular drive.
Switching times cannot be set on tubular drive.	Programmed transmitter has no manual/ auto slide switch.	Use transmitter with manual/auto slide switch.
Tubular drive does not operate at the set switching time.	Manual/auto slide switch at  .	Switch manual/auto slide switch to  .
	More than one slide switch transmitter is programmed on the tubular drive. One manual/auto slide switch is at  .	Switch the slide switch on one transmitter from  to  . If the slide switch is already at  , switch it to  and back to  .
Set switching times change.	Frequent 230 V AC power cuts. Fluctuations in the 50 Hz mains frequency.	
During the programming run, the drive stops short of the limit position to be programmed.	For safety reasons, the drive reacts sensitively to unsmooth running during the programming run, in order to prevent damage.	Briefly run curtain DOWN and subsequently UP until you reach the upper limit position.
Ventilation slots of the roller shutter do not close fully.	Unsmooth running of the roller shutter near the lower stop and setting of the "lower stop" limit position.	Delete the limit positions (see Deleting the limit positions [→ 15]) and set the limit positions as per "to lower point" (Setting the limit positions); to this end, first programme the lower limit position (lower point) and then the upper limit position.

Sample wiring diagram



Declaration of conformity

BECKER-ANTRIEBE GMBH
Friedrich-Ebert-Str. 2-4
35764 Sinn, Germany



BECKER

- Original -

EC Declaration of Conformity

Document No./Month . Year: **K004/02.13**

We hereby declare that the following product series

Product designation: **Tubular motor with integrated radio receiver**

Type designation: **R8/17.., R12/17.., R20/17.., R30/17.., R40/17.., R50/11..,
P5/16.., P3/30.., P5/30.., P5/20.., P9/16.., P13/9.., P4/16..,
L44/14.., L50/11.., L50/17.., L60/11.., L60/17.., L70/17.., L80/11..,
L80/17.., L120/11..**

Version: **C, R, S, F, P, E, O, A0...Z9, +**

From serial number: **from 130600001**

complies with the applicable regulations of the following Directives:

Machinery Directive (2006/42/EC)

R&TTE Directive (1999/5/EC)

Furthermore, the safety objectives of the **Low Voltage Directive 2006/95/EC** as per Appendix I No.1.5.1 of Directive 2006/42/EC have been met.

Applied harmonised standards:

EN 60335-1:2012

EN 60335-2-97:2010

EN 61000-6-3:2007

ETSI EN 301489-3:2002

EN 14202:2004

Authorised party for the compilation of the technical documentation:
Becker-Antriebe GmbH, Friedrich-Ebert-Str. 2-4, 35764 Sinn, Germany

This declaration of conformity was issued:

Sinn, 4.2.2013
Place, Date


D. Fuchs, Management

This declaration certifies compliance with the Directives cited but does not represent any assurance of characteristics.

The safety warnings in the supplied product documentation must be observed!

